


GLOSS

GLOSS HAND TOWEL RAIL

SPECIFICATIONS



AVAILABLE IN



GS893
Chrome



GS893-40
Brushed Nickel



GS893-31
Brushed Carbon



GS893 MB
Matte Black



GS893-24
Brushed Bronze



GS893-12
Brushed Gold

INFORMATION



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.