



GLOSS

GLOSS ROBE HOOK



SPECIFICATIONS



AVAILABLE IN



GS897
Chrome



GS897-40
Brushed Nickel



GS897-31
Brushed Carbon



GS897 MB
Matte Black



GS897-24
Brushed Bronze



GS897-12
Brushed Gold

INFORMATION



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.