


LEXI MKII

LEXI MKII SOAP DISH HOLDER

SPECIFICATIONS



AVAILABLE IN



123-8300-00
Chrome



123-8300-40
Brushed Nickel



123-8300-10
Matte Black

INFORMATION



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
- Any damage caused in this way will not be covered by warranty.

Please visit <https://www.phoenixtapware.com.au/warranty> to view the full warranty